



# TERM10 User guide



# Wiring diagram

Connect to carrier HDMI INPUT connector

Connect desired clock on CLK IN



Connect to carrier HDMI OUT connector

Optional. Use as a master output if using slave systems. Connect to slave HDMI IN.

Modified clock output visible on CLK OUT

# Additions to sync\_role

A new option to sync\_role has been added to work alongside the term10 – rpmaster. This allows the system to be a master system, clocked from the rear panel, rather than from the front or from the internal clock.

The command can be used as such:


```
acq1001_349> set.site 0 sync_role rpmaster 200k
```

or

```
acq1001_349> set.site 0 sync_role rpmaster 2M
```


# Before using rpmaster command

Here is the configuration of the system before using the rpmaster command. Note – this system has a  
set.site 0 sync\_role master 200000  
command in rc.user.



# Using rpmaster command


Here is the configuration of the same system immediately after using:  
set.site 0 sync\_role rpmaster 200k



# Example rpmaster commands

`sync_role` can now take any clock parameter passed to it. For example (and demonstration purposes only as acq423 max clock speed is 200k) here is `rpmaster` with an argument of 2M.

```
set.site 0 sync_role rpmaster 2M
```



# Scope trace of input and output from TERM10.

Here is the scope trace of the signal generator clock input on C3 (orange trace) and the d0 (EXT clock) output from the TERM10 on C4 (purple trace). The phase difference is approximately 80ns.

Please note that the 'rpmaster' command does NOT set this routing. To check this you will have to manually set the clock output selection to d0.



# Scope trace of input and output from TERM10.

Here is the scope trace of the signal generator clock input on C3 (orange trace) and the d1 (MBCLK) output from the TERM10 on C4 (purple trace).

